

The Essential Coffee Cart Assembly Instructions

Tools Needed:

- 9/16 Socket
- Philips screwdriver
- Flat head screwdriver
- 4mm / 5/32 hex key

Step 1: Secure the Casters

1. Locate the panel labeled "base." Ensure the side with holes for barrel nuts faces upward, as this is the base of the cabinet.
2. Secure the four casters to the base panel using the provided bolts, nuts, and washers.
 - Place the flat washers on the top side of the panel (where the bolt head rests).
 - Use a crush washer on the underside (where the nut secures the bolt).
 - Tighten each bolt firmly to ensure the casters are stable.

Step 2: Install Left Side Panel

1. Locate the "left" side panel. Place three barrel nuts into the designated holes on the left side of the base panel.
 - Use a flathead screwdriver to align the barrel nuts with the adjacent screw holes for proper threading.
2. Align the side panel with the base panel. Insert three crib screws through the side panel and fasten them into the barrel nuts.
3. Tighten securely to ensure a strong connection.

Step 3: Install Front Panel

1. Locate the "front" panel. Place ten barrel nuts into the designated holes on the front panel.
 - Use a flathead screwdriver to align the barrel nuts with the adjacent screw holes.
2. Insert three crib screws through the left side panel and two crib screws through the base panel, fastening them into the left-5 barrel nuts on the front panel.
3. Tighten all screws to secure the front panel firmly.

Step 4: Install Right Side Panel

1. Locate the "right" side panel. Place three barrel nuts into the designated holes on the right side of the base panel.
 - Use a flathead screwdriver to align the barrel nuts with the adjacent screw holes for proper threading.
2. Align the side panel with the base and front panels. Insert six crib screws through the right side panel, fasten them into the barrel nuts.
3. Tighten securely to ensure a strong connection.

Step 5: Install Center Divider

1. Locate the "center" divider. Secure four figure-8 fasteners to the cutouts on the front and top edges of the center divider using four provided screws.
2. Insert the two remaining barrel nuts into the designated holes in the center divider.
3. Insert the two remaining crib screws through the underside of the base panel, fastening them into the two barrel nuts in the center divider.
4. Tighten securely to ensure a strong connection.
5. Fasten two additional screws through the front-two figure-8 fasteners on the front of the center divider, securing it to the front panel.

Step 6: Install Countertop

1. Secure eight figure-8 fasteners to the cutouts on the top edges of the side and front panels using eight provided screws.
2. Place the countertop onto the assembled frame, aligning it with all ten figure-8 fasteners.
3. Insert the remaining 10 screws through all the figure-8 fasteners into the countertop and tighten securely.

Tip: *For a stronger, permanent assembly, apply wood glue to the joints if you don't plan to disassemble the cart.

The Essential Coffee Cart Components

Each cart kit contains the following components:

Hardware:

- 18 barrel nut bolts
- 18 barrel nuts
- 12 figure eight clips
- 24 screws for the figure eight clips
- 4 casters
- 16 bolts for casters
- 16 washers for casters
- 16 lock washers for casters

Panels:

- Base/Bottom
- Right Side
- Left Side
- Center Divider
- Front
- Countertop

Let us know how we can help!

Prima Coffee Equipment
Email: sales@prima-coffee.com
Call: (888) 837-7892

PRIMA
COFFEE EQUIPMENT